

Installation and Operating Instructions



3" Submersible Deep Well Pumps

TABLE OF CONTENTS

PURCHASER'S INFORMATION

PURCHASER'S INFORMATION	2
GENERAL DESCRIPTION	3
GENERAL SAFETY INFORMATION	4
INSTALLATION	5
TYPICAL INSTALLATION	7
PIPEWORK CONNECTIONS	8
ELECTRICAL CONNECTIONS	10
START-UP	12
TROUBLESHOOTING	13
TECHNICAL DATA	14
CABLE SELECTION CHART	15
WIRING DIAGRAMS	16

Pump Model #:	_____
Pump Serial #:	_____
Motor Model #:	_____
Motor Serial #:	_____
Dealer Name:	_____
Dealer Telephone:	_____
Purchase Date:	_____
Installation Date:	_____
Volts:	_____
Amps:	_____

GENERAL DESCRIPTION

NORTHAM Submersible Pumps and Motors shall provide you with years of reliable, efficient and safe pumping solution for your water needs provided the installation is carried out as described in this manual.

Before installing, operating, using, or maintaining the submersible pump and/or motor, it's essential to read these instructions. Additionally ensure that the submersible pump and/or motor is not utilized until all safety conditions outlined in the instruction manual are satisfied.

The purpose of the instructions, warnings, cautions and notes included in this manual is to help you become familiar with the product and its allowed uses.

The instructions may not take into account local regulations; ensure such regulations are properly complied by all, including those installing the product. Ensure that installation and operation adhere to local regulations and accepted standards of good practice.

These instructions apply specifically to NORTHAM submersible pumps and motors. If the pump or motor is coupled or is going to be coupled with a motor or pump of any other make other than NORTHAM, then kindly refer to instructions provided with the submersible motor or pump of other make and ignore the motor or pump instructions provided in this manual.

Before proceeding with installation, carefully review these instructions for safe and proper installation.

SYMBOLS USED IN THIS DOCUMENT



Warning

Neglecting these safety instructions could result in explosion, fire or electric shock, posing a significant risk of severe personal injury, or even death, as well as property damage.

Caution

Failure to adhere to these safety instructions may lead to equipment malfunction or damage.

Note

These notes or instructions aim to streamline the task and ensure safe operation.

GENERAL SAFETY INFORMATION



During installation, operation as well as servicing of the submersible pumps and/or submersible motors follow safety instructions as listed below. Failure to follow these instructions may result in electrical shock, fire hazard, personal injury or death, equipment damage, inadequate product performance and may also void manufacturer's warranty.

SAFETY INSTRUCTIONS

- The pump and/or motor should be installed, connected to power source and serviced by qualified electrician only.
- During installation, operation as well as servicing of the pump and/or motor, do not touch any electrical components when power supply is switched on.
- Ensure all power sources are disconnected and locked in OFF position when installing or repairing the pump and/or motor.
- Follow all appropriate electrical codes.
- Always follow the National Electrical Code (NEC), or the Canadian Electrical Code. Check local codes and regulations before installation. The installation must comply with these requirements.
- Failure to follow electrical codes & OSHA safety standards could lead to personal injury or death and may also lead to damage of the equipment.
- The pumps and motors are not designed and investigated for safety when used in swimming pools.
- Do not use to pump flammable, combustible, or explosive liquids such as gasoline, oil, kerosene, etc.
- This pump should be used to pump clear water only
- Please wear protective clothes and safety glasses for personal protection when installing or repairing the pump and/or motor.
- Operators should be properly instructed on operating procedures & safety guidelines.
- During installation make sure that the lifting apparatus is properly tightened before attempting to lift the pump and/or motor. Carelessness during lifting or transportation may cause injury to personnel or damage to the pump and/or motor.
- Pump and/or motor must be lifted manually or by means of a hoist. Never lift the pump and/or motor by means of the motor cable.
- Assembled pumping units and their components are heavy. Failure to properly lift and support equipment can result in serious physical injury and/or equipment damage.
- Pump must be installed in a vertical position or Horizontal installation.
- Pump with Motor should always be electrically grounded. Motor cable shall only be connected to power source after grounding is done.
- Motor must be completely submerged in water when it is used.
- Lock the mains switch in "OFF" position when maintenance is progress.
- Do not put your hands or any tool into the pump suction or discharge port after the pump has been connected to the power supply, unless the pump has been switched off by removing the fuses or switching off and locking the mains switch in OFF position. It must be ensured that the power supply cannot be accidentally switched on.
- Never disassemble the motor.
- Never use the motor in combination with damaged pump units or parts.
- Do not run pump dry. Dry running can overheat pump and will void warranty.
- Always use only original genuine factory spare parts.
- Please keep out of the reach of children.

INSTALLATION



Before commencing the installation, ensure to turn off the power supply and securely lock the main switch in the OFF position.

Caution Avoid starting the pump to check the direction of rotation until it has been fully immersed in water.

PRE-INSTALLATION CHECKLIST

Before initiating the installation procedures, please conduct the following checks:

- Inspect all components for potential damage during transit and notify the shipping carrier or your dealer/distributor if any damage is found.
- Confirm that the power supply at site matches with motor nameplate power supply requirements.
- The mounting location of the controller should be dry and shaded.
- Use waterproof splice connections for all splices which are underwater and underground.
- Inspect all piping connections to ensure they are tight and sealed with PTFE thread sealing tape.
- Confirm that the pressure rating of the pipe is higher than the shut-off pressure of the pump.
- Install a pressure relief valve on any pumping system when the pump shut off pressure exceeds the recommended working pressure of the pressure tank.
- Inspect the condition of the well for proper installation.
- Check the condition of the water and ensure that it is compatible with material of construction of the pump and motor.
- Check water temperature being pumped to ensure it does not exceed more than the maximum temperature of service declared by the manufacturer of pump and motor. Ensure that the flow of water on surface of the motor in the well exceeds the minimum velocity required for proper cooling of the motor.
- Prepare the motor for installation and add cable length as required based on depth of installation. Prepare for installation of piping and pipe work connections.

All of these checks are essential for correctly installing the submersible pump and it's imperative to adhere to all safety regulations during the installation process.



The pump must always be connected to a suitable electrical ground, such as a grounded water pipe, a grounded metal pathway, or a grounded wire system.



Do not put your hands or any tool into the pump suction or discharge port after the pump has been connected to the power supply, unless the pump has been switched off by removing the fuses or switching off the mains switch. It must be ensured that the power supply cannot be accidentally switched on.



Do not lift the pump and/or motor by power cable. Only use the lifting apparatus for lifting the pump. Do not use it to hold the pump when in operation.

Caution **THE WARRANTY SHALL BECOME VOID UNDER THE FOLLOWING CIRCUMSTANCES**

- If the pump has pumped an excessive amount of sand, it can lead to premature wear and damage to the pump.
- If the water is corrosive or contaminated with dirt.
- If there is entrained gas or air in the water being pumped, it can decrease the flow and lead to cavitation, potentially causing damage to the pump.
- Operating the pump with discharge valve closed may result in severe internal damage due to increase in temperature of water.
- Damage resulting from failure to install the product as specified in the owner's manual.
- Damage caused by unauthorized product modifications or failure to use NORTHAM original replacement parts.
- Damage caused by negligence, or failure to properly maintain product as specified in the owner's manual.
- Accidental damage, fire, acts of God, or other circumstances outside the control of NORTHAM.

INSTALLATION

CONDITION OF THE WELL

For installation of the pump in a new well, ensure the well is fully developed by using compressed air to clear the sand from the well.

The careful selection of materials used in construction of NORTHAM submersible pump offers resistant to abrasion; nevertheless, no material regardless of its composition, can indefinitely withstand the erosive effects of continuous pumping of sand-laden water.

Determine the maximum well depth and the draw-down level when the pump operates at maximum capacity. Use this data to select pump and determine the appropriate setting depth.

Ensure that the inside diameter of the well casing is adequate for pump installation.

INSTALLATION DEPTH

- Verify that the pump is installed at a depth of at least 30 feet below the maximum draw-down level of the well to ensure optimal operation.
- Avoid positioning the bottom of the motor lower than the top of the well screen or within 5 feet of the well bottom.
- When installing the pump in a lake, pond, tank or large diameter well, ensure that the water velocity passing over the motor is adequate for proper cooling.

POSITIONAL REQUIREMENTS

The pump can be positioned vertically or horizontally. However, as shown in fig. 1 the installation position should never fall below the horizontal plane.





Fig. 1 PUMP POSITION

TYPICAL INSTALLATION

TYPICAL INSTALLATION WITH HYDRO PNEUMATIC PRESSURE TANK



NOTES:
 * For installation which are more than 200' in depth additional check valves are to be installed at every 200'.
 - Adjustment to the pre-charge pressure of the tank must be performed using the air valve located on the top of the tank

Fig. 2 TYPICAL PUMP INSTALLATION

PIPEWORK CONNECTIONS

Ensure that the pump discharge pipes are adequately sized to optimize pump performance.

Recommended pipe size:

Up to 10 GPM - 1"
Up to 30 GPM - 1¼"
Up to 45 GPM - 1½"
Up to 80 GPM - 2"

Note

It is advisable to use larger pipe size for long pipe runs.
You can contact your pipe supplier, for suitable pipe size.

HYDRO PNEUMATIC PRESSURE TANK

The Hydro Pneumatic Pressure tank should be placed in dry and well ventilated location.

Caution Select a location where any tank leakage won't result in damage to the property.

Ensure that the pressure switch is positioned no more than 4' away from the tank, ideally it should be located at the tank's cross tee.

Caution To prevent switch chatter, do not install valves and filters between the switch and the tank.

Position the pressure switch as centrally as possible when installing multiple tanks. For this set-up, use a header pipe with a diameter at least 1.5 times larger than the supply pipe from the pump to minimize friction loss in the header pipe.

Install a pressure relief valve in the system capable of handling pressures up to 100 psi or 230' of TDH.

To check the pre-charge pressure of tank, use a high quality pressure gauge and measure after emptying the tank. The pressure should be set 2 to 5 psi below the pump cut-in pressure. As an instance, a 30-50 psi system would require a tank pre-charge of 28 to 25 psi.

DISCHARGE PIPE

Most discharge outlet of the pump are threaded onto the housing with left-hand threads. When installing accessories, only hold the pump at the discharge outlet. Failure to secure the discharge outlet can cause it to loosen and damage the pump during start-up.

If the adapter for piping is required, stainless steel is recommended to avoid corrosion. Never connect fittings other than stainless steel directly to a stainless steel discharge outlet to prevent corrosion in the piping.

The pump discharge outlet comes with a loop for attaching a safety cable. It's always advisable to use a safety cable when using polyethylene or any plastic pipe, as the pipe stretches when under pressure and in case of pipe failure the pump can be prevented to fall in the well.

RISER PIPE

If a tool (e.g. a chain pipe wrench) is used when the riser pipe is fitted to the pump, the pump must only be gripped by the pump discharge outlet.

The threaded portion on the riser pipe must be well cut and fit on the discharge outlet threads of the pumps easily. Ensure that riser pipe would not get loose in operation due to torque reaction caused by the starting and stopping of the pump. The thread on the first section of the riser pipe which is to be screwed into the pump outlet should not be longer than the threads in the pump.

If noise may be transmitted to the building through the pipework, it is advisable to use plastic pipes.

PIPEWORK CONNECTIONS

INSTALLING PUMP IN WELL

Before lowering the pump, it's recommended to inspect the borehole inside diameter using an inside calliper to ensure that the motor and pump can easily be lowered in the well and there is no possibility of it getting stuck during installation.

Gently lower the pump into the borehole, being cautious not to damage the motor cable or the submersible drop cable.

Caution Do not lower or lift the pump/motor using the motor cable.

When using a torque arrestor it is advisable to install it according to the instructions provided by the seller or the manufacturer of the torque arrestor.

Use discharge pipe when lowering the pump into the well. Install the pump in the well by means of pitless adaptor or similar device at the wellhead and follow the instructions provided by it's manufacturer.

While lowering the pump and motor in the well, secure the cable to the discharge pipe at 10' intervals by using waterproof electrical tape. Clip-on type connectors also can be used to connect it with discharge pipe.

CHECK VALVES

We insist that a check valve must be provided within 25 feet of pump discharge outlet to prevent back-flow once the pump is stopped. A check valve is strongly recommended to maintain constant pressure in the pumping system and also prevent premature bearing wear, damage caused by back-flow of the pump and motor. It also prevents water hammer and upward thrust damage.

Additional Check valves should be installed in 200' interval for the installations deeper than 200'. Kindly refer fig. 2 for check valve placement recommendations.

GENERAL

The electrical connections should be carried out by an authorised electrician in accordance with local regulations.



Always follow the National Electrical Code (NEC), or the Canadian Electrical Code. Also check local codes and regulations.



Before making any connections to the pump motor, make sure that the electricity supply is switched off and that it cannot be accidentally switched on by locking the mains in OFF position. The pump, motor, controller, and mains switch must be grounded.

The operating voltage and frequency are stated on the motor nameplate. Make sure that the motor is suitable for the electricity supply at the installation site.

CABLE SPLICING



At the time of joining motor cable with additional length of cable, precaution should be taken that the cable splicing is done so that no moisture or water can enter the joints of the cable.

Waterproof splicing is required when the drop cable is connected to the motor cable or when drop cable is to be spliced. The process can be done with either heat shrink kits or waterproof tape.

ELECTRICAL CONNECTIONS

METHOD 1 : USING HEAT SHRINK SPLICE

1. For each wire, carefully remove about ½" of the insulation protecting the copper strands.
2. Insert shrink tubing onto one wire.
3. Crimp butt connector on both wires.
4. Center shrink tubing over the splice.
5. Hot air heating of tubing should begin in the center and slowly work its way to one end while maintaining the heat source moving. Then shrink the same way to opposite end from center. Avoid extreme heat above 120° F to prevent damage to heat shrink tube. One may use a little gas torch or an electric heat gun. Once the tubing shrinks to shape and sealant oozes from the ends, the splice is accomplished. Stagger the location of the splices on all the wires so as not to create a big bundle.




Fig. 3 HEAT SHRINK SPLICING

For splicing with a significant difference between wire sizes, an additional shrink sleeve can be shrunk to on the smaller wire so that it can be tight enough for the bigger sleeve. For your specific application, refer to the instructions provided in the splice kit.

Once all the wires are spliced they can be bunched together and then a tight wrap of electrical tape can be done to secure them together.

METHOD 2 : USING TAPE SPLICE

Cable joint can be done carefully with the tape as described below.

1. As shown in fig. 4 cut the cable in a staggered manner for cable joining.
2. Strip individual conductor of insulation only as far as needed for a dowel type connector or a neatly twisted joint. If a twisted joint is used, it is essential that it be soldered. Tubular connectors of dowel are always preferred over soldering. (If connector o.d. is not as large as cable insulation build up with rubber electrical tape).
3. Tape individual joints with rubber electrical tape using two layers, the first extending 2 inch beyond each end of the conductor insulation end, the second layer 2 inch beyond the ends of first layer. Wrap tightly, eliminating airspaces as much as possible.
4. Tape over the rubber electrical tape with #33 Scotch electrical tape using two layers as in step #3 & making each layer overlap the end of preceeding layer by at least 2 inch.
5. Total thickness of joint after taping should not be less then conductor insulation. Add additional tape layers if required.




Fig. 4 TAPE SPLICING

ELECTRICAL CONNECTIONS

CONNECTING MOTOR LEADS TO MOTOR CONTROL BOX, PRESSURE SWITCH OR STARTER



Always follow the National Electrical Code (NEC), or the Canadian Electrical Code. Also check local codes and regulations. Do not turn on unit or start the pump until all electrical and piping connections have been made. Before connecting the pressure switch line wires to the power source, make sure the circuit breaker or disconnect switch is locked in OFF position

Connect the ground wire identified by its Green color, to the designated Green ground screw and both the Black motor leads to the pressure switch's load terminals.

Complete the wiring by connecting the single-phase pressure switch line connections to the circuit breaker panel or disconnect switch where used.

For manual start connect the pump to a suitable single phase starter with On/Off push button.

BUILT IN PROTECTION

The pump has an inbuilt electronic unit which protects the motor in case of ;

- 1.Dry running
- 2.Over voltage
- 3.Under voltage
- 4.Over temperature
- 5.Overload

In case of any fault the pump will stop for 20 seconds. After this period the pump will attempt to restart. If the fault condition is not resolved then the power supply to the pump shall be electronically cut-off after 20 attempts to restart. In this condition in order to start the pump again, switch off the power supply for 1 minute to reset and switch on power supply again.

If the pump has stopped pumping due to dry running, it will start automatically after 20 minutes.

START-UP

For a new well it is required to install discharge valve on the pump discharge line. When the pump has been connected correctly and it is submerged in the liquid to be pumped, it should be started with the discharge valve open to approx. 1/3 of its maximum volume of water.

If there are impurities or sand in the water, the valve should be opened gradually as the water becomes clearer.

The pump should not be stopped until the water is completely clean, as otherwise the pump parts and the non-return valve may choke up with sand or mud. Turn the pump power off when water runs clear.

Remove the discharge valve from the pump's discharge line and connect it to the home plumbing, pressure tank and switch. Turn on the electricity and run a few cycles through the tank to rinse it and ensure that the pump and switch are operating properly

TROUBLESHOOTING



Before removal/dismantling of the pump, make sure that the electricity supply has been switched off and locked in OFF position and cannot be accidentally switched on. All rotating parts must have stopped moving.

FAULT	CAUSE	REMEDY
THE PUMP/MOTOR DOES NOT RUN..	<ol style="list-style-type: none"> 1) The fuses are blown. 2) The circuit breaker has tripped out. 3) Inadequate power supply. 4) No electricity supply. 5) Motor has tripped out, due to incorrect/faulty electrical connections, low voltage, high voltage, dry running, over load, higher ambient temperature and locked pump. 6) The motor/power cable is defective. 	<ol style="list-style-type: none"> 1) Replace the blown fuses. If the new ones blow too, the electric installation and the submersible drop cable should be checked for insulation resistance. 2) Cut in the circuit breaker. 3) Check power supply or generator capacity. 4) Contact the electricity supply company. 5) The motor electronic control shall automatically restart the pump after 20 seconds. After 20 re attempts to start the pump power supply has to be switched off for 1 minute to reset and then pump can be started again. 6) Repair/replace the motor/cable.
THE PUMP RUNS BUT DELIVERS LITTLE OR NO WATER.	<ol style="list-style-type: none"> 1) Faulty or incorrectly installed check valve. 2) The pump is defective/worn. 3) Pump is air locked. 4) Pump is locked due to sand. 5) The inlet strainer is choked up. 6) Lift is too high for pump. 7) Pump not fully submerged. 	<ol style="list-style-type: none"> 1) Repair/replace the check valve. 2) Repair/replace the pump. 3) Repeatedly start & stop pump until it delivers flow. 4) Pull out the pump & clean it. adjust depth if required, 5) Pull out the pump and clean the strainer. 6) Check the pump performance 7) Lower the pump if possible.
MOTOR STARTS AND STOPS TOO OFTEN	<ol style="list-style-type: none"> 1) Setting of pressure switch limits not set properly or pressure switch is defective 2) The check valve is leaking or stuck open. 3) Leakage in the system. 4) The pressure tank is too small or has failed. 	<ol style="list-style-type: none"> 1) Readjust the pressure switch settings or replace the switch if required. 2) Pull out the pump and clean/replace the check valve. 3) Replace damage pipes or repair leaks. 4) Replace the pressure tank with adequate capacity.
MOTOR RUNS CONTINUOUSLY	<ol style="list-style-type: none"> 1) Leakage in the system. 2) The pump is defective/worn. 3) Pressure switch setting may be too high. Switch contacts may be "welded" in closed position. 4) The inlet strainer is choked up. Pump may installed in mud/sand. 5) The check valve is stuck in closed position and no water will be delivered. 	<ol style="list-style-type: none"> 1) Replace damage pipes or repair leaks. 2) Repair/replace the pump. 3) Readjust the pressure switch settings/replace it if required. Clean switch contacts. 4) Pull out the pump and clean the strainer. It may be necessary to clean the well. 5) Replace it if defective.
OVERLOAD PROTECTOR TRIPPED OUT	<ol style="list-style-type: none"> 1) Worn pump/motor. 2) Defective motor or cable 3) Incorrect voltage 	<ol style="list-style-type: none"> 1) Repair/replace the pump/motor. 2) Repair/replace the motor/cable.. 3) Contact electricity supply company if voltage is incorrect.

TECHNICAL DATA

MOTOR INSULATION RESISTANCE READINGS

Normal Ohms/megaohms, all motors, between all wires and ground.



Before starting insulation resistance measurement make sure that the electricity supply is switched off and that it cannot be accidentally switched on by locking the mains in OFF position.

Caution

Perform an insulation resistance test by opening the circuit breaker and disconnecting all wires from the control box or pressure switch. Connect one ohmmeter or meggar lead to one motor lead and the other to a metal drop pipe of good ground, R X 100K scale.

CONDITION OF MOTOR AND LEADS	OHM VALUE	MEGOHM VALUE
New motor, without power cable	20,000,000 (or more)	20.0
Used motor, which can be reinstalled in well	10,000,000 (or more)	10.0
MOTOR IN WELL – READINGS ARE FOR POWER CABLE PLUS MOTOR		
New motor	2,000,000 (or more)	2.0
Motor in reasonably good condition	500,000 to 2,000,000	0.5 – 2.0
Motor which may be damaged or have damaged power cable Do not pull motor for these reasons	20,000 to 500,000	0.02 – 0.5
Motor definitely damaged or with damaged power cable Pull motor and repair	10,000 to 20,000	0.01 – 0.02
Failed motor or power cable Pull motor and repair	Less than 10,000	0 – 0.01

CABLE SELECTION CHART

CABLE SIZING

Note Cable size given here are for Copper wire. If aluminum conductor is used, multiply lengths by 0.5.
 Maximum allowable length of aluminum is considerably shorter than copper wire of same size.
 Cable size are based on Service Factor Amps, 30° C Ambient and 5% Voltage Drop.

Motor (P2)	I(n)	Maximum cable length (ft)			
		16 AWG	14 AWG	12 AWG	10 AWG
[KW]	[A]				
1.0	9.0	187	312	499	755
1.5	14	121	203	322	486

SINGLE PHASE MOTORS




Fig. 5 Connection diagram for installation using pressure switch

NOTES

NOTES

NOTES



Northam Inc.

995/C Griffin Pond Road, Clarks Summit, PA 18411, USA
www.northam-inc.com
